





DIMENSIONS




MOUNTING INSTRUCTION

1 Mount the base on the ceiling with screws (fastening elements are included).

2 Insert the cable from the top or from the side. Cut the gasket to insert it from the side.

3 **POWER CONNECTION**
Connect to 220-240V.




4 Attach the luminaire to the mounting base by clicking it in as shown.

5 Choose the correct setting according to the table.




Driver must be powered off before changing the settings.



DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1** Push the clips on both sides to remove the luminaire from the mounting base.
- 2** Disconnect the wires and unscrew the driver to remove the driver.
- 3** Pull down the cover.
- 4** Disconnect the wires and loosen the screws to remove the light source.



The light source is replaceable by Wever & Ducré or by a professional with explicit authorization. For more information please contact your local Wever & Ducré customer service point.



The driver can be replaced by the end user.

This luminaire contains a light source with the corresponding energy class:

Version	Energy class
ROSS 1.0	A ↑ G E
ROSS 2.0	A ↑ G D
ROSS 3.0	A ↑ G C

