




MICK WALL

INSTALLATION INSTRUCTIONS | JULY 2023




DIMENSIONS



MOUNTING INSTRUCTION



- 1 Loosen the four socket screws from the fixture.
- 2 Remove the mounting base from the fixture and mount it on the wall with screws (screws are not included).
- 3 POWER CONNECTION
Connect to 220-240V.





- 4 Attach the fixture to the mounting base by sliding it over completely against the wall.
- 5 Lock the fixture on the mounting base with the four socket screws.



Do not change the standard settings of the driver!







Mounting base:



MICK WALL

INSTALLATION INSTRUCTIONS | JULY 2023



DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1 Loosen the four socket screws from the fixture to remove it from the mounting base.
- 2 Disconnect the wires and remove the driver.
- 3 Pull out the lens cover.
- 4 Take out all parts to and unscrew the light source to remove it.



The light source is replaceable by an authorized professional. For advice contact your Wever & Ducré customer service contact point.



The driver can be replaced by the end user.



This luminaire contains a light source with the energy class D.