

Installation Instructions



www.bdk-luminaire.ch



NOTICE

1. This fitting requires 220-240V AC/50HZ power input to the driver.
2. Do not interchange any parts of this fitting.
3. Do not touch fixture when in use.
4. Do not cover with any form of heat proof material.

