



BLIEK PETIT CEILING SURFACE

INSTALLATION INSTRUCTIONS | MAY 2023



DIMENSIONS




2.0



MOUNTING INSTRUCTION

1 Loosen the socket screws and remove the mounting base from the fixture and mount it on the ceiling with screws (screws are not included).

2 POWER CONNECTION
Connect to 220-240V.




3 Fix the luminaire on the base with the socket screws.



Only to be installed outside arms reach.

BLIEK PETIT CEILING SURFACE


INSTALLATION INSTRUCTIONS | MAY 2023



DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1 Loosen the socket screws from the fixture to remove it from the mounting base.
- 2 Disconnect the wires and remove the driver.
- 3 Dismount the lens holder and all parts behind to remove the light sources.



The light source is replaceable by an authorized professional.
For advice contact your Wever & Ducré customer service contact point.

Every luminaire contains a light source with the corresponding energy class:

colour temperature	Energy class
2700K/3000K	A ↑ E
2000-3000K	A ↑ G