



DEEP point IP44

INSTALLATION INSTRUCTIONS | MARCH 2023



DIMENSIONS




MOUNTING INSTRUCTION


1 Make a hole in the ceiling according to the prescribed dimensions.

2 POWER CONNECTION


Always use a power supply according to the specifications of the LED module.



SERIAL CONNECTION




3 Push the springs upwards and insert the fixture in the ceiling hole.




  Before connecting the luminaire/LED module to the driver please make sure the driver is not powered but disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module.

Driver must be powered off before connecting cables.



DEEP point IP44


INSTALLATION INSTRUCTIONS | MARCH 2023



DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source

- 1 Take the luminaire out of the ceiling hole and disconnect the wires.
- 2 Break the glass.
- 3 Take out the lens and unscrew the light source to remove it.



The light source is not replaceable.



This luminaire contains a light source with the energy class E.