



LINOO RECESSED

INSTALLATION INSTRUCTIONS | FEBRUARY 2026




Power must be switched off before changing the colour temperature.



Driver must be powered off before connecting the cables.

Before connecting the luminaire/LED module to the driver please make sure the driver is not powered but disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module.



DIMENSIONS

1.0	40		36x39	60	4-28
2.0	40		36x67	60	4-28
4.0	40		118x36	60	4-28
4.1	40		63x59	60	4-28
8.0	40		226x36	60	4-28

MOUNTING INSTRUCTION


- Make a hole in the ceiling according to the prescribed dimensions.
- POWER CONNECTION**
 Always use a driver according to the specifications of the LED module.

Single connection

Multiple connection
- Change the colour temperature with the switch on the backside. The power must be switched off before changing the colour temperature.
- Push the springs upwards and insert the fixture in the ceiling hole.


LINOO RECESSED

INSTALLATION INSTRUCTIONS | FEBRUARY 2026



DISMOUNTING INSTRUCTION Light source


- 1** Take the luminaire out of the ceiling hole and unplug the wires.
- 2** Remove the reflector and lenses by loosening the screws.
- 3** Unscrew the light source to remove it.



The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.



This luminaire contains a light source with the energy class F.



Use green electricity to light up your luminaire.