



DIMENSIONS




MOUNTING INSTRUCTION

- 1** Loosen the four socket screws from the fixture.
 - 2** Remove the mounting base from the fixture and mount it on the ceiling with screws (screws are not included).
 - 3** POWER CONNECTION
Connect to 220-240V.
-
- 4** Attach the fixture to the mounting base by sliding it over completely against the ceiling.
 - 5** Lock the fixture on the mounting base with the four socket screws.


Mounting base:






1


2



3



4




DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1 Loosen the four socket screws from the fixture to remove it from the mounting base.
- 2 Disconnect the wires and remove the driver.
- 3 Pull out the lens cover.
- 4 Take out all parts to and unscrew the light source to remove it.



The light source is replaceable by an authorized professional. For advice contact your Wever & Ducré customer service contact point.



The driver can be replaced by the end user.



This luminaire contains a light source with the energy class D.