



QITO SURFACE

INSTALLATION INSTRUCTIONS | FEBRUARY 2026



DIMENSIONS





MOUNTING INSTRUCTION

- 1 Loosen the socket screw to remove the mounting base.
- 2 Mount the mounting base on the ceiling with screws (screws are not included).

3 POWER CONNECTION



Connect to 220-240V.

Connect the earth cable.








- 4 Fix the luminaire on the mounting base with the socket screw.

Mounting base:




QITO SURFACE

INSTALLATION INSTRUCTIONS | FEBRUARY 2026



DISMOUNTING INSTRUCTION Light source & driver

- 1 Loosen the socket screw to remove the fixture from the mounting base.
- 2 Remove the LED engine(s) from the housing by loosening the screws.
- 3 Pull out the snoot and lens.
- 4 Disconnect the wires and unscrew the light source to remove it.
- 5 Remove the driver by pulling.




The driver can be replaced by the end user.



The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.



This luminaire contains a light source with the energy class D.



Use green electricity to light up your luminaire.