



SOLID 1.0

INSTALLATION INSTRUCTIONS | DECEMBER 2022



DIMENSIONS





MOUNTING INSTRUCTION

- 1 First assemble the LED module and housing.
- 2 Mount the base plate to the ceiling with screws (screws are not included).
- 3 Push the springs up and insert the assembled unit in the luminaire tube body until it touches the step.
- 4 **POWER CONNECTION**
Connect to 220-240V.
DALI


DALI - Purple	to primary DALI
DALI - Grey	to primary DALI
V+ - Red	to LED
V- - Black	to LED
L - Brown	to primary AC
N - Blue	to primary AC

phase cut
- 5 Attach the tube to the mounting base by sliding it over completely against the ceiling.
Note: the side with the slot should be upwards to lock the springs of the ceiling base plate.

Mounting base:




Before connecting the luminaire/LED module to the driver please make sure the driver is not powered but disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module.



SOLID 1.0

INSTALLATION INSTRUCTIONS | DECEMBER 2022




DISMANTLING AND RECYCLING INSTRUCTIONS

Light source & driver

- 1 Pull down the luminaire from the ceiling base.
- 2 Unscrew and unplug the driver to remove it.
- 3 Push in the slot of the spring clip and pull it down to remove the LED module
- 4 Remove the fixture from the tube.
- 5 Push at the three points to loosen the front ring.
- 6 Take the components out to remove the light source.



The driver can be replaced by the end user.



The light source is replaceable by an authorized professional.
For advice contact your Wever & Ducré customer service contact point.



This luminaire contains a light source with the energy class D.



WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV

Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com